How do I tune the channels on my Samsung TV?

Just complete the following **steps**.

Before you begin

- Some steps on your TV may **differ** from **the steps shown below**
- Do not **insert your CI+ module** into your TV until **after** you have scanned the channels!
- Your TV must be set to **TV** and not **HDMI**. You can easily check this by pressing the **source** button on your remote control
- If you are asked to enter a **PIN code** and have **forgotten** it, try one of the **default PIN codes**: 0000, 1111 or 1234

- Press the **Menu** button on your remote control
- Select **Channel** and press **OK** on your remote control. For **Antenna** you must choose the **Cable** option
- Go to **Automatic tuning** and press **OK twice** on your remote control
    - Set the **Automatic tuning** screen to **Cable** (vertical) and **Digital** (horizontal)
    - Then press **OK** on your remote control
- Enter the following **values**:
    - Search mode: **Quick**
    - Network: **Manual**
    - Network ID: the code for your region (**22** for Flanders and **12** for Brussels)
- Press **OK** on your remote control
- For **Frequency** enter the value **322000** and press **OK** on your remote control
- For **Modulation** enter the value **256QAM** and for **Symbol frequency** enter the value **6875**. Then select **Search** (or **Next**, this differs by type of TV) and press **OK** on your remote control
- **Your TV now scans the channels**
- Now continue with **steps 4, 5 and 6** in the **'TV with a card' manual**